CAD-feature-based tool-path definition (CAD2Path)

Process & tool-paths - Robot Offline Programming · https://convergent-it.com/tutorial/process-and-tool-paths/cad-feature-based-definition/

Deburring, line-welding, sealing, (spme) gluing are processes wher the tool follows a feature, such as a weld - which is defined in the CAD data - and thus it is most naturally and ergonomic to define the path to follow a CAD feature.

For this software functionality, a CAD description which possesses CAD features (edges etc.) is required. That is e.g. STEP or IGES. STL and other formats do not include CAD-features.

The following videos show use-cases how to define such a path for the case of welding

The video is embedded by YouTube and only loaded and played from there when you click on the play button. From then on, the privacy policy of Google applies.

The following video shows more details for a more simple case:

The video is embedded by YouTube and only loaded and played from there when you click on the play button. From then on, the privacy policy of Google applies.